

X-Stand Plus


R1.060515



- 3 Aluminium rods joined by a connector
- 2 Fiberglass reinforced plastic rods
- Carrying Case


X-STAND PLUS

1




1. Fit the plastic rods into the sleeves of the plastic connector

2




2. Press the button in the center of the connector to unfold the rods to the width of the display

3



3. Fix the grommets on the corners of the image to the hooks at the Fiberglass rod ends

4



4. Stand the display up, folding back the center Aluminium rod to a position that suits best



AMERICA'S SUPERSTORE FOR CHURCH BANNERS, DISPLAY SYSTEMS & INSPIRATIONAL PRODUCTS

PO Box 1024 | Gallatin Tennessee 37066-1024 USA | 615.206.8400 or 615.395.8024 | customerservice@banners4churches.com
www.banners4churches.com | banners4churches.printesto.com